



Jamaica Cottage Shop, Inc.
170 Winhall Station Rd. South Londonderry, VT 05155
(866) 297-3760
plans@JamaicaCottageShop.com

8x18 Heritage - Shopping List

Floor Frame

Hemlock
2- 6x6x18' Skids
8-2x6x8'
7-2x6x10'
3-2x6x12'
1-2x6x14'

Posts & Beams, Braces

Hemlock
1- 4x4x8'
2- 4x4x10'
2-4x4x12'
7-4x4x14'

4-2x4x8'
5-2x4x10'
1-2x4x12'
2-2x4x14'

Roof

Hemlock
11- 2x6x10'
2-2x4x8'
1- 1x8x14'
3- 1x8x10'
2-1x8x8'
5- 1x6x10'
3-1x12x10'
5- 1x6x10'
6- 1x4x14'
4-1x4x10'

Extra Lumber- Temporary bracing

2-2x4x8'- Hemlock
7-1x4x10'-Pine
2-1x12x14'-Pine
1-3/4x2x14'-Pine

Siding- Pine

3-1x6x10'
4 - 1x8x8'
12 - 1x8x10'
6 - 1x10x8'
6 - 1x10x10'
31-1x12x8'
2-1x12x12'

6-2x8x8' rip for battens
3-2x8x10' rip for battens

Trim- Pine

Windows Trim, Shadow,
Corner, Door
21- 1x4x8'
5- 1x4x12'

5- 2x8x10'
1- 2x8x12'
5-2x4x10'
1-2x4x12'

1-1x10x6' rip to 5"
2-1x10x8' rip to 5"
2-1x10x10' rip to 5"
4-1x6x8' rip to 3"
2-1x4x12' rip to 2"

**Contact us today to
purchase a Hardware
Package to match this
set of plans.**

Please contact us with any mistakes or discrepancies in these plans.
We strive to provide our clients with a quality product and encourage
feedback.



10x20 Heritage Material List

Floor- Hemlock

14-2x6x12' Skids & Joists
14-2x6x10'- Joists
8-2x6x8' Skids

Walls-Hemlock

4-4x4x14' Posts
7-4x4x12' Beams/ Angle Braces
1-4x4x10' Beams
3-2x4x14' Door posts
3-2x4x12' Window Sill & Headers
8-2x4x10' Blocking , Headers, & Nailers
3-2x4x8' Nailers

Roof-Hemlock

13- 2x6x12' Rafters
1-2x6x8' Jack Rafters
1-1x12x14' Ledger Boards
6-1x12x12' Sheathing
1-1x8x12' Ridge Pole
2-1x8x8' Ridge Pole
5-1x6x10' Collar ties
1-1x4x14' Roof Strapping
7-1x4x12' Roof Strapping
2-1x4x10' Roof Strapping
9-1x4x8' Roof Strapping

Temp Bracing/ Extra Lumber

7-1x4x10' Hemlock- Bracing
1-2x4x12' Hemlock- Extra Lumber
2-1x12x12'-Pine Extra Lumber
4-3/4x2 x10' Extra Battens

Trim-Pine

4-2x8x14' Fascia
4-2x8x10' Fascia
3-2x4x14' Shadow
2-2x4x10' Shadow
2-2x4x8' Shadow
1-1x4x14' Window & Door Trim
3-1x4x12' Window & Door Trim
2-1x4x10' Door Trim
15-1x4x8' Corner Trim
1-1x10x14'-Rip to 1x5 Door casing
1-1x10x12'-Rip to 1x5 Door casing
2-1x6x14'-Rip to 1x3 Window stops
1-1x4x14'- Rip to 1x2 Door stops
1-1x4x12'- Rip to 1x2 Door stops

Siding-Pine

2-1x12x12'
2-1x12x10'
34-1x12x8'
2-1x10x12'
13-1x10x10'
4-1x10x8'
2-1x8x12'
2-1x3x10'

Battens- rip to 3/4"

8-2x8x8'
3-2x8x10'

Interior- Pine

2-1x12x12'
2-1x12x10'
4-1x8x8'
1-1x6x8'



10x20 Heritage Mill Work & Hardware

Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"
1-JCS 3-0 Door B 36x80-1/2"
1- JCS Door A 30-1/8"x71-3/8"
2-2x2x Six Light hinged windows
1-3x2 Eight light Hinged Windows
1- Louvered Wood vent
16" Vent Batten

Hardware

10lbs-16D Framing Nails
5lbs-16D Galv Nails for trim
8lbs-8D HDG Hand Nails-Galv
5lbs-6D HDG Hand Nails-Galv
10-Closure Board Screws-1-1/2"
500-Roofing Screws
90-Door Hinge Screws-Black
1-1/4" Hex Bit
1-#2 Square Drive Bit

9-8" Black Door Hinges
1-Foot Bolt
1-Chain Bolt
3-Turn Latch Black

7- Window Hinges-Black
30-Window Hinge Screws
3-Window Hooks & Eyes

Corrugated Roofing

18-Pieces of Roofing @38" W x75" L

2-Pieces Ridge Cap @126"
1-Pieces Ridge Cap @80"
1-Pieces Ridge Cap @52"

Additional Lumber

8-3/4" 4x8 CDX Plywood
1-2x6x14' Pressure treated (Ramp)
3-1x6x12' Pressure Treated(Ramp)

Suggested Tools

Skill Saw or Hand saw Saw-z-all
Hammer
Nail puller (cats paw or crow bar)
25' tape measure
Chalk line
Extension Cord
Tin Snips
Staple gun
Pencil
Speed Square
Four-foot level Cordless Drill
1/4" drive bit for drill
#2 Phillips
#2 Square Drive
Razor
Knife
Chisel
Ladder



10x24 Heritage Material List

Floor- Hemlock

12-2x6x16'-Skids
2-2x6x14' Rim Joists
10-2x6x12' Joists & Blocking
10-2x6x10' Joists

Walls-Hemlock

2-4x4x16' Beams
5-4x4x14' Posts
6-4x4x12' Beams & Angle Braces
1-4x4x10' Beam
3-2x4x14' Door posts & Blocking
4-2x4x12' Sills & Door posts
5-2x4x10' Window Framing
7-2x4x8' Nailers
1-1x4x4'

Roof-Hemlock

15-2x6x12' Rafters
1-2x6x8' Jack Rafters
1-1x12x14' Ledger Boards
6-1x12x12' Sheathing
2-1x8x12' Ridge Pole
2-1x8x8' Ridge Pole
6-1x6x10' Collar ties
1-1x4x14' Roof Strapping
15-1x4x12' Roof Strapping
2-1x4x10' Roof Strapping
2-1x4x8' Roof Strapping

Temp Bracing/ Extra Lumber

7-1x4x10' Hemlock- Bracing
1-2x4x16' Hemlock- Extra Lumber
2-1x12x16'-Pine Extra Lumber

Trim-Pine

1-2x8x16' Fascia
4-2x8x14' Fascia
1-2x4x16' Shadow
5-2x4x14' Shadow

3-1x4x14' Window & Door Trim
3-1x4x12' Window & Door Trim
2-1x4x10' Door Trim
12-1x4x8' Corner Trim
1-1x10x14'-Rip to 1x5 Door casing
1-1x10x12'-Rip to 1x5 Door casing
2-1x6x14'-Rip to 1x3 Window stops
1-1x4x14'- Rip to 1x2 Door stops
1-1x4x12'- Rip to 1x2 Door stops

Siding-Pine

2-1x12x12'
2-1x12x10'
34-1x12x8'
2-1x10x12'
13-1x10x10'
4-1x10x8'
2-1x8x12'
2-1x3x10'

Battens- rip to 3/4"

4-2x8x14'
2-2x8x10'
4-2x8x8'

Interior- Pine

2-1x12x12'
2-1x12x10'
4-1x8x8'
1-1x6x8'



10x24 Heritage Mill Work & Hardware

Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"
1-JCS 3-0 Door B 36x80-1/2"
1- JCS Door A 30-1/8"x71-3/8"
2-2x2x Six Light hinged windows
1-3x2 Eight light Hinged Windows
1- Louvered Wood vent
16" Vent Batten

Hardware

10lbs-16D Framing Nails
6lbs-16D HDG Hand Nails-Galv
10lbs-8D HDG Hand Nails-Galv
5lbs-6D HDG Hand Nails-Galv
10-Closure Board Screws-1-1/2"
550-Roofing Screws
90-Door Hinge Screws-Black
1-1/4" Hex Bit
1-#2 Square Drive Bit

9-8" Black Door Hinges
1-Foot Bolt
1-Chain Bolt
3-Turn Latch Black

7- Window Hinges-Black
30-Window Hinge Screws
3-Window Hooks & Eyes

Additional Lumber

8-3/4" 4x8 CDX Plywood
1-2x6x14' Pressure treated (Ramp)
3-1x6x12' Pressure Treated(Ramp)

Suggested Tools

Skill Saw or Hand saw Saw-z-all
Hammer
Nail puller (cats paw or crow bar)
25' tape measure
Chalk line
Extension Cord
Tin Snips
Staple gun
Pencil
Speed Square
Four-foot level Cordless Drill
1/4" drive bit for drill
#2 Phillips
#2 Square Drive
Razor
Knife
Chisel
Ladder

Corrugated Roofing

21-Pieces of Roofing @38" W x75" L

3-Pieces Ridge Cap @126"
1-Pieces Ridge Cap @48"



12x20 Heritage Material List

Floor- Hemlock

4-2x6x16' Skids
13-2x6x14' Joists & Blocking
14-2x6x12' Skids & Joists
10-4x8 Sheets 3/4"CDX

Walls-Hemlock

7-4x4x14' Posts & Beams
1-4x4x12' Beam
5-4x4x10' Beams & Angle Braces
2-2x4x16' Wall Framing
5-2x4x14' Wall Framing
5-2x4x12' Wall Framing
6-2x4x10' Wall Framing

Roof-Hemlock

14-2x6x14' Rafters-Hemlock
7-1x12x14' Sheathing -Pine
2-1x8x14' Ridge Pole-Hemlock
6-1x6x14' Collar Ties & Sheathing-Hemlock
4-1x4x14' Strapping-Hemlock
2-1x4x14' Strapping-Hemlock
4-1x4x10' Strapping-Hemlock

Temp Bracing/ Extra Lumber

5-1x4x12' Hemlock- Bracing
1-2x4x16' Hemlock- Extra Lumber
1-1x12x16'-Pine Extra Lumber

Interior- Pine

6-1x12x10'
2-1x12x8'
3-1x8x8'
1-1x6x8'

Trim-Pine

1-2x8x14' Fascia
1-2x8x10'
2-2x8x8'
2-1x8x14'
2-1x8x8'

2-2x4x14' Shadow
1-2x4x10'
2-1x4x14'
1-1x4x8'
1-1x4x12' Door Trim
3-1x4x10' Window Trim
21-1x4x8' Corner/Door/Window Trim

2-1x5x14' Door casing
2-1x5x12'

1-1x3x14' Window Stops
2-1x3x10'
2-1x3x8'

2-1x2x14' Door Stops
2-1x2x12'

Siding-Pine

1-1x12x14'
2-1x12x12'
25-1x12x10'
20-1x12x8'
2-1x10x10'
5-1x10x8'
2-1x8x12'
4-1x8x10'
1-1x8x8'

Battens- rip to 3/4"

12-2x8x8'
5-2x8x10'



12x20 Heritage Mill Work & Hardware

Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"
1-JCS 3-0 Door B 36x80-1/2"
1- JCS Door A 30-1/8"x71-3/8"
2-4x2x Ten Light hinged windows
2-3x2 Eight light Hinged Windows
1- Louvered Wood vent
16" Vent Batten

Hardware

12bs-16D Framing Nails
6lbs-16D HDG Hand Nails-Galv
15lbs-8D HDG Hand Nails-Galv
5bs-6D HDG Hand Nails-Galv
10-Closure Board Screws-1-1/2"
600-Roofing Screws
110-Door Hinge Screws-Black
1-1/4" Hex Bit
1-#2 Square Drive Bit

11-8" Black Door Hinges
1-Foot Bolt
1-Chain Bolt
3-Turn Latch Black

12- Window Hinges-Black
50-Window Hinge Screws
8-Window Hooks & Eyes

Corrugated Roofing

16-Pieces of Roofing @38" W x82" L

3-Pieces Ridge Cap @126"
1-Pieces Ridge Cap @72 "

Additional Lumber

10-3/4" 4x8 CDX Plywood
1-2x6x14' Pressure treated (Ramp)
3-1x6x12' Pressure Treated(Ramp)

Suggested Tools

Skill Saw or Hand saw Saw-z-all
Hammer
Nail puller (cats paw or crow bar)
25' tape measure
Chalk line
Extension Cord
Tin Snips
Staple gun
Pencil
Speed Square
Four-foot level Cordless Drill
1/4" drive bit for drill
#2 Phillips
#2 Square Drive
Razor
Knife
Chisel
Ladder



12x24 Heritage Material List

Floor- Hemlock

13-2x6x16' Skids & Rim Joists
7-2x6x14' Floor Joists
9-2x6x12 Floor Joists
6-2x6x10' Joist Blocking
1-2x6x8' Rim Joist

Walls-Hemlock

10-4x4x14' Post & Beams
3-4x4x12' Beams & Angle Braces
2-4x4x10' Beams & Angle Braces
1-4x4x8' Beam
3-2x4x14' Door posts
13-2x4x12' Window Framing& Door Headers
2-2x4x10' Door blocking
2-2x4x8' Door blocking

Roof-Hemlock

8-2x6x14' Rafters
1-2x6x12' Rafters
1-2x6x10' Rafters
7-1x12x14' Roof Sheathing-PINE
2-1x12x8' Ledger Boards-PINE
1-1x8x14' Ridge Pole
1-1x8x10' Ridge Pole
1-1x8x8' Ridge Pole
7-1x6x14' Collar Ties & Roof Sheathing
5-1x4x14' Roof Strapping
3-1x4x12' Roof Strapping
6-1x4x10' Roof Strapping
5-1x4x8' Roof Strapping

Temp Bracing/ Extra Lumber

6-1x4x14' Hemlock- Bracing
1-2x4x14' Hemlock- Extra Lumber
1-1x12x14'-Pine Extra Lumber

Trim-Pine

2-2x8x14' Fascia
2-2x8x8' Fascia
2-1x8x14' Fascia
1-1x8x12' Fascia
1-2x4x16' Shadow
2-2x4x14' Shadow
2-1x4x14' Shadow
2-1x4x12' Shadow & Door Trim
4-1x4x10' Window Trim
20-1x4x8' Corner Trim & Door Trim

1-1x10x14' Rip to 5" Door Casing
1-1x10x10' Rip to 5" Door Casing
5-1x6x8' Rip to 3" Window Stops
1-1x4x14' Rip to 2" Door Stops
1-1x4x12' Rip to 2" Door Stops

Siding-Pine

30-1x12x8'
25-1x12x10'
2-1x12x12'
1-1x10x10'
2-1x8x14'
4-1x8x10'
5-1x8x8'

Battens- rip to 3/4"

12-2x8x8'
2-2x8x10'

Interior- Pine

6-1x12x10'
2-1x12x8'
3-1x8x8'
1-1x6x8'



12x24 Heritage Mill Work & Hardware

Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"
1-JCS 3-0 Door B 36x80-1/2"
1- JCS Door A 30-1/8"x71-3/8"
2-4x2x Ten Light hinged windows
2-3x2 Eight light Hinged Windows
1- Louvered Wood vent
16" Vent Batten

Hardware

12bs-16D Framing Nails
6lbs-16D HDG Hand Nails-Galv
15lbs-8D HDG Hand Nails-Galv
7bs-6D HDG Hand Nails-Galv
10-Closure Board Screws-1-1/2"
700-Roofing Screws
110-Door Hinge Screws-Black
1-1/4" Hex Bit
1-#2 Square Drive Bit

11-8" Black Door Hinges
1-Foot Bolt
1-Chain Bolt
3-Turn Latch Black

12- Window Hinges-Black
30-Window Hinge Screws
8-Window Hooks & Eyes

Corrugated Roofing

19-Pieces of Roofing @38" W x82" L

3-Pieces Ridge Cap @126"
1-Pieces Ridge Cap @72 "

Additional Lumber

10-3/4" 4x8 CDX Plywood
1-2x6x14' Pressure treated (Ramp)
3-1x6x12' Pressure Treated(Ramp)

Suggested Tools

Skill Saw or Hand saw Saw-z-all
Hammer
Nail puller (cats paw or crow bar)
25' tape measure
Chalk line
Extension Cord
Tin Snips
Staple gun
Pencil
Speed Square
Four-foot level Cordless Drill
1/4" drive bit for drill
#2 Phillips
#2 Square Drive
Razor
Knife
Chisel
Ladder