



Jamaica Cottage Shop, Inc.  
170 Winhall Station Rd. South Londonderry, VT 05155  
(866) 297-3760  
[plans@JamaicaCottageShop.com](mailto:plans@JamaicaCottageShop.com)

## 8x18 Heritage - Shopping List

### Floor Frame

Hemlock  
2- 6x6x18' Skids  
8-2x6x8'  
7-2x6x10'  
3-2x6x12'  
1-2x6x14'

### Posts & Beams, Braces

Hemlock  
1- 4x4x8'  
2- 4x4x10'  
2- 4x4x12'  
7- 4x4x14'

4- 2x4x8'  
5- 2x4x10'  
1- 2x4x12'  
2- 2x4x14'

### Roof

Hemlock  
11- 2x6x10'  
2- 2x4x8'  
1- 1x8x14'  
3- 1x8x10'  
2- 1x8x8'  
5- 1x6x10'  
3- 1x12x10'  
5- 1x6x10'  
6- 1x4x14'  
4- 1x4x10'

### Extra Lumber- Temporary bracing

2- 2x4x8' - Hemlock  
7- 1x4x10' - Pine  
2- 1x12x14' - Pine  
1- 3/4x2x14' - Pine

### Siding- Pine

3- 1x6x10'  
4- 1x8x8'  
12- 1x8x10'  
6- 1x10x8'  
6- 1x10x10'  
31- 1x12x8'  
2- 1x12x12'  
  
6- 2x8x8' rip for battens  
3- 2x8x10' rip for battens

### Trim- Pine

Windows Trim, Shadow,  
Corner, Door  
21- 1x4x8'  
5- 1x4x12'

5- 2x8x10'  
1- 2x8x12'  
5- 2x4x10'  
1- 2x4x12'

1- 1x10x6' rip to 5"  
2- 1x10x8' rip to 5"  
2- 1x10x10' rip to 5"  
4- 1x6x8' rip to 3"  
2- 1x4x12' rip to 2"

**Contact us today to  
purchase a Hardware  
Package to match this  
set of plans.**

Please contact us with any mistakes or discrepancies in these plans.  
We strive to provide our clients with a quality product and encourage  
feedback.



## 10x20 Heritage Material List

### Floor- Hemlock

14-2x6x12' Skids & Joists  
14-2x6x10'- Joists  
8-2x6x8' Skids

### Walls-Hemlock

4-4x4x14' Posts  
7-4x4x12' Beams/ Angle Braces  
1-4x4x10' Beams  
3-2x4x14' Door posts  
3-2x4x12' Window Sill & Headers  
8-2x4x10' Blocking , Headers, & Nailers  
3-2x4x8' Nailers

### Roof-Hemlock

13- 2x6x12' Rafters  
1-2x6x8' Jack Rafters  
1-1x12x14' Ledger Boards  
6-1x12x12' Sheathing  
1-1x8x12' Ridge Pole  
2-1x8x8' Ridge Pole  
5-1x6x10' Collar ties  
1-1x4x14' Roof Strapping  
7-1x4x12' Roof Strapping  
2-1x4x10' Roof Strapping  
9-1x4x8' Roof Strapping

### Temp Bracing/ Extra Lumber

7-1x4x10' Hemlock- Bracing  
1-2x4x12' Hemlock- Extra Lumber  
2-1x12x12'-Pine Extra Lumber  
4-3/4x2 x10' Extra Battens

### Trim-Pine

4-2x8x14' Fascia  
4-2x8x10' Fascia  
3-2x4x14' Shadow  
2-2x4x10' Shadow  
2-2x4x8' Shadow  
1-1x4x14' Window & Door Trim  
3-1x4x12' Window & Door Trim  
2-1x4x10' Door Trim  
15-1x4x8' Corner Trim  
1-1x10x14'-Rip to 1x5 Door casing  
1-1x10x12'-Rip to 1x5 Door casing  
2-1x6x14'-Rip to 1x3 Window stops  
1-1x4x14'- Rip to 1x2 Door stops  
1-1x4x12'- Rip to 1x2 Door stops

### Siding-Pine

2-1x12x12'  
2-1x12x10'  
34-1x12x8'  
2-1x10x12'  
13-1x10x10'  
4-1x10x8'  
2-1x8x12'  
2-1x3x10'

### Battens- rip to 3/4"

8-2x8x8'  
3-2x8x10'

### Interior- Pine

2-1x12x12'  
2-1x12x10'  
4-1x8x8'  
1-1x6x8'



## 10x20 Heritage Mill Work & Hardware

### Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"  
1-JCS 3-0 Door B 36x80-1/2"  
1- JCS Door A 30-1/8"x71-3/8"  
2-2x2x Six Light hinged windows  
1-3x2 Eight light Hinged Windows  
1- Louvered Wood vent  
16" Vent Batten

### Hardware

10lbs-16D Framing Nails  
5lbs-16D Galv Nails for trim  
8lbs-8D HDG Hand Nails-Galv  
5lbs-6D HDG Hand Nails-Galv  
10-Closure Board Screws-1-1/2"  
500-Roofing Screws  
90-Door Hinge Screws-Black  
1-1/4" Hex Bit  
1-#2 Square Drive Bit  
  
9-8" Black Door Hinges  
1-Foot Bolt  
1-Chain Bolt  
3-Turn Latch Black  
  
7- Window Hinges-Black  
30-Window Hinge Screws  
3-Window Hooks & Eyes

### Corrugated Roofing

18-Pieces of Roofing @38" W x75" L  
  
2-Pieces Ridge Cap @126"  
1-Pieces Ridge Cap @80"  
1-Pieces Ridge Cap @52"

### Additional Lumber

8-3/4" 4x8 CDX Plywood  
1-2x6x14' Pressure treated ( Ramp)  
3-1x6x12' Pressure Treated( Ramp)

### Suggested Tools

Skill Saw or Hand saw Saw-z-all  
Hammer  
Nail puller (cats paw or crow bar)  
25' tape measure  
Chalk line  
Extension Cord  
Tin Snips  
Staple gun  
Pencil  
Speed Square  
Four-foot level Cordless Drill  
1/4" drive bit for drill  
#2 Phillips  
#2 Square Drive  
Razor  
Knife  
Chisel  
Ladder



## 10x24 Heritage Material List

### Floor- Hemlock

12-2x6x16'-Skids  
2-2x6x14' Rim Joists  
10-2x6x12' Joists & Blocking  
10-2x6x10' Joists

### Walls-Hemlock

2-4x4x16' Beams  
5-4x4x14' Posts  
6-4x4x12' Beams & Angle Braces  
1-4x4x10' Beam  
3-2x4x14' Door posts & Blocking  
4-2x4x12' Sills & Door posts  
5-2x4x10' Window Framing  
7-2x4x8' Nailers  
1-1x4x4'

### Roof-Hemlock

15-2x6x12' Rafters  
1-2x6x8' Jack Rafters  
1-1x12x14' Ledger Boards  
6-1x12x12' Sheathing  
2-1x8x12' Ridge Pole  
2-1x8x8' Ridge Pole  
6-1x6x10' Collar ties  
1-1x4x14' Roof Strapping  
15-1x4x12' Roof Strapping  
2-1x4x10' Roof Strapping  
2-1x4x8' Roof Strapping

### Temp Bracing/ Extra Lumber

7-1x4x10' Hemlock- Bracing  
1-2x4x16' Hemlock- Extra Lumber  
2-1x12x16'-Pine Extra Lumber

### Trim-Pine

1-2x8x16' Fascia  
4-2x8x14' Fascia  
1-2x4x16' Shadow  
5-2x4x14' Shadow

3-1x4x14' Window & Door Trim  
3-1x4x12' Window & Door Trim  
2-1x4x10' Door Trim  
12-1x4x8' Corner Trim  
1-1x10x14'-Rip to 1x5 Door casing  
1-1x10x12'-Rip to 1x5 Door casing  
2-1x6x14'-Rip to 1x3 Window stops  
1-1x4x14'- Rip to 1x2 Door stops  
1-1x4x12'- Rip to 1x2 Door stops

### Siding-Pine

2-1x12x12'  
2-1x12x10'  
34-1x12x8'  
2-1x10x12'  
13-1x10x10'  
4-1x10x8'  
2-1x8x12'  
2-1x3x10'

### Battens- rip to 3/4"

4-2x8x14'  
2-2x8x10'  
4-2x8x8'

### Interior- Pine

2-1x12x12'  
2-1x12x10'  
4-1x8x8'  
1-1x6x8'



## 10x24 Heritage Mill Work & Hardware

### Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"  
1-JCS 3-0 Door B 36x80-1/2"  
1- JCS Door A 30-1/8"x71-3/8"  
2-2x2x Six Light hinged windows  
1-3x2 Eight light Hinged Windows  
1- Louvered Wood vent  
16" Vent Batten

### Hardware

10lbs-16D Framing Nails  
6lbs-16D HDG Hand Nails-Galv  
10lbs-8D HDG Hand Nails-Galv  
5lbs-6D HDG Hand Nails-Galv  
10-Closure Board Screws-1-1/2"  
550-Roofing Screws  
90-Door Hinge Screws-Black  
1-1/4" Hex Bit  
1-#2 Square Drive Bit  
  
9-8" Black Door Hinges  
1-Foot Bolt  
1-Chain Bolt  
3-Turn Latch Black  
  
7- Window Hinges-Black  
30-Window Hinge Screws  
3-Window Hooks & Eyes

### Additional Lumber

8-3/4" 4x8 CDX Plywood  
1-2x6x14' Pressure treated ( Ramp)  
3-1x6x12' Pressure Treated( Ramp)

### Suggested Tools

Skill Saw or Hand saw Saw-z-all  
Hammer  
Nail puller (cats paw or crow bar)  
25' tape measure  
Chalk line  
Extension Cord  
Tin Snips  
Staple gun  
Pencil  
Speed Square  
Four-foot level Cordless Drill  
1/4" drive bit for drill  
#2 Phillips  
#2 Square Drive  
Razor  
Knife  
Chisel  
Ladder

### Corrugated Roofing

21-Pieces of Roofing @38" W x75" L  
  
3-Pieces Ridge Cap @126"  
1-Pieces Ridge Cap @48"



## 12x20 Heritage Material List

### **Floor- Hemlock**

4-2x6x16' Skids  
13-2x6x14' Joists & Blocking  
14-2x6x12' Skids & Joists  
10-4x8 Sheets 3/4"CDX

### **Walls-Hemlock**

7-4x4x14' Posts & Beams  
1-4x4x12' Beam  
5-4x4x10' Beams & Angle Braces  
2-2x4x16' Wall Framing  
5-2x4x14' Wall Framing  
5-2x4x12' Wall Framing  
6-2x4x10' Wall Framing

### **Roof-Hemlock**

14-2x6x14' Rafters-Hemlock  
7-1x12x14' Sheathing -Pine  
2-1x8x14' Ridge Pole-Hemlock  
6-1x6x14' Collar Ties & Sheathing-Hemlock  
4-1x4x14' Strapping-Hemlock  
2-1x4x14' Strapping-Hemlock  
4-1x4x10' Strapping-Hemlock

### **Temp Bracing/ Extra Lumber**

5-1x4x12' Hemlock- Bracing  
1-2x4x16' Hemlock- Extra Lumber  
1-1x12x16'-Pine Extra Lumber

### **Interior- Pine**

6-1x12x10'  
2-1x12x8'  
3-1x8x8'  
1-1x6x8'

### **Trim-Pine**

1-2x8x14' Fascia  
1-2x8x10'  
2-2x8x8'  
2-1x8x14'  
2-1x8x8'  
  
2-2x4x14' Shadow  
1-2x4x10'  
2-1x4x14'  
1-1x4x8'  
1-1x4x12' Door Trim  
3-1x4x10' Window Trim  
21-1x4x8' Corner/Door/Window Trim  
  
2-1x5x14' Door casing  
2-1x5x12'  
  
1-1x3x14' Window Stops  
2-1x3x10'  
2-1x3x8'  
  
2-1x2x14' Door Stops  
2-1x2x12'

### **Siding-Pine**

1-1x12x14'  
2-1x12x12'  
25-1x12x10'  
20-1x12x8'  
2-1x10x10'  
5-1x10x8'  
2-1x8x12'  
4-1x8x10'  
1-1x8x8'

### **Battens- rip to 3/4"**

12-2x8x8'  
5-2x8x10'



## 12x20 Heritage Mill Work & Hardware

### Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"  
1-JCS 3-0 Door B 36x80-1/2"  
1- JCS Door A 30-1/8"x71-3/8"  
2-4x2x Ten Light hinged windows  
2-3x2 Eight light Hinged Windows  
1- Louvered Wood vent  
16" Vent Batten

### Hardware

12bs-16D Framing Nails  
6lbs-16D HDG Hand Nails-Galv  
15lbs-8D HDG Hand Nails-Galv  
5bs-6D HDG Hand Nails-Galv  
10-Closure Board Screws-1-1/2"  
600-Roofing Screws  
110-Door Hinge Screws-Black  
1-1/4" Hex Bit  
1-#2 Square Drive Bit  
  
11-8" Black Door Hinges  
1-Foot Bolt  
1-Chain Bolt  
3-Turn Latch Black  
  
12- Window Hinges-Black  
50-Window Hinge Screws  
8-Window Hooks & Eyes

### Corrugated Roofing

16-Pieces of Roofing @38" W x82" L  
  
3-Pieces Ridge Cap @126"  
1-Pieces Ridge Cap @72 "

### Additional Lumber

10-3/4" 4x8 CDX Plywood  
1-2x6x14' Pressure treated ( Ramp)  
3-1x6x12' Pressure Treated( Ramp)

### Suggested Tools

Skill Saw or Hand saw Saw-z-all  
Hammer  
Nail puller (cats paw or crow bar)  
25' tape measure  
Chalk line  
Extension Cord  
Tin Snips  
Staple gun  
Pencil  
Speed Square  
Four-foot level Cordless Drill  
1/4" drive bit for drill  
#2 Phillips  
#2 Square Drive  
Razor  
Knife  
Chisel  
Ladder



## 12x24 Heritage Material List

### Floor- Hemlock

13-2x6x16' Skids & Rim Joists  
7-2x6x14' Floor Joists  
9-2x6x12 Floor Joists  
6-2x6x10' Joist Blocking  
1-2x6x8' Rim Joist

### Walls-Hemlock

10-4x4x14' Post & Beams  
3-4x4x12' Beams & Angle Braces  
2-4x4x10' Beams & Angle Braces  
1-4x4x8' Beam  
3-2x4x14' Door posts  
13-2x4x12' Window Framing & Door Headers  
2-2x4x10' Door blocking  
2-2x4x8' Door blocking

### Roof-Hemlock

8-2x6x14' Rafters  
1-2x6x12' Rafters  
1-2x6x10' Rafters  
7-1x12x14' Roof Sheathing-PINE  
2-1x12x8' Ledger Boards-PINE  
1-1x8x14' Ridge Pole  
1-1x8x10' Ridge Pole  
1-1x8x8' Ridge Pole  
7-1x6x14' Collar Ties & Roof Sheathing  
5-1x4x14' Roof Strapping  
3-1x4x12' Roof Strapping  
6-1x4x10' Roof Strapping  
5-1x4x8' Roof Strapping

### Temp Bracing/ Extra Lumber

6-1x4x14' Hemlock- Bracing  
1-2x4x14' Hemlock- Extra Lumber  
1-1x12x14'-Pine Extra Lumber

### Trim-Pine

2-2x8x14' Fascia  
2-2x8x8' Fascia  
2-1x8x14' Fascia  
1-1x8x12' Fascia  
1-2x4x16' Shadow  
2-2x4x14' Shadow  
2-1x4x14' Shadow  
2-1x4x12' Shadow & Door Trim  
4-1x4x10' Window Trim  
20-1x4x8' Corner Trim & Door Trim

1-1x10x14' Rip to 5" Door Casing  
1-1x10x10' Rip to 5" Door Casing  
5-1x6x8' Rip to 3" Window Stops  
1-1x4x14' Rip to 2" Door Stops  
1-1x4x12' Rip to 2" Door Stops

### Siding-Pine

30-1x12x8'  
25-1x12x10'  
2-1x12x12'  
1-1x10x10'  
2-1x8x14'  
4-1x8x10'  
5-1x8x8'

### Battens- rip to 3/4"

12-2x8x8'  
2-2x8x10'

### Interior- Pine

6-1x12x10'  
2-1x12x8'  
3-1x8x8'  
1-1x6x8'





## 12x24 Heritage Mill Work & Hardware

### Mill-work

2-JCS Barn Doors D-30-1/8"x80-3/8"  
1-JCS 3-0 Door B 36x80-1/2"  
1- JCS Door A 30-1/8"x71-3/8"  
2-4x2x Ten Light hinged windows  
2-3x2 Eight light Hinged Windows  
1- Louvered Wood vent  
16" Vent Batten

### Hardware

12bs-16D Framing Nails  
6lbs-16D HDG Hand Nails-Galv  
15lbs-8D HDG Hand Nails-Galv  
7bs-6D HDG Hand Nails-Galv  
10-Closure Board Screws-1-1/2"  
700-Roofing Screws  
110-Door Hinge Screws-Black  
1-1/4" Hex Bit  
1-#2 Square Drive Bit  
  
11-8" Black Door Hinges  
1-Foot Bolt  
1-Chain Bolt  
3-Turn Latch Black  
  
12- Window Hinges-Black  
30-Window Hinge Screws  
8-Window Hooks & Eyes

### Corrugated Roofing

19-Pieces of Roofing @38" W x82" L  
  
3-Pieces Ridge Cap @126"  
1-Pieces Ridge Cap @72 "

### Additional Lumber

10-3/4" 4x8 CDX Plywood  
1-2x6x14' Pressure treated ( Ramp)  
3-1x6x12' Pressure Treated( Ramp)

### Suggested Tools

Skill Saw or Hand saw Saw-z-all  
Hammer  
Nail puller (cats paw or crow bar)  
25' tape measure  
Chalk line  
Extension Cord  
Tin Snips  
Staple gun  
Pencil  
Speed Square  
Four-foot level Cordless Drill  
1/4" drive bit for drill  
#2 Phillips  
#2 Square Drive  
Razor  
Knife  
Chisel  
Ladder